

Smart Classroom Instructions: TLP 700

Power: Turns the projector on and off. A pop-up will appear for projector off, confirming if you want to turn the projector off.

AV Mute: Mutes the sound and blacks out the signal to the projector. You will still be able to see the image at the podium.

Screen Control: Raises and lowers the projection screen.



Volume: Turns the sound level up or down. Sound is adjusted with the knob under this bar. The amplifier may have a brief delay in response.

Inputs: Clicking on an input will switch to that source. Inputs in specific rooms may vary.

Laptop will switch to the VGA cable, and HDMI will switch to the HDMI cable, both are available in the cable cubby.

Some rooms will have a laptop button, you will then be prompted to pick VGA or HDMI.